

Aeroforce Interceptor Application guide

Rev 02/14/16

Make	Year	Motor	Interceptor version	Part Number
Audi (not yet available for all models)				
All 2008+ Audi vehicles will us the CNAV series gauge - not yet available				
A3	2000-2007	all	ISOAV series	ISOAVx01
A3	2008-2009	all	NA	
S3	2000-2007	all	ISOAV series	ISOAVx01
S3	2008-2009	all	NA	
A4	2000-2004	all	ISOAV series	ISOAVx01
A4	2005-2009	all	NA	
S4	2000-2002	all	ISOAV series	ISOAV01
S4	2003-2004	all	ISOAV series	
A5	2007-2009	all	NA	
S5	2007-2009	all	NA	
A6	2000-2004	all	ISOAV series	ISOAV01
A6	2005-2009	all	NA	
S6	2000-2004	all	ISOAV series	ISOAVx01
A8			NA	
A8			NA	
S8			NA	
S8			NA	
TT	2000-2006	all but 3.2	ISOAV series	ISOAVx01
TT	all	3.2 V6	n/a	
TT	2007+	all but 3.2	NA	

Notes: PT series = standard General Motors gauge (pre-CAN)

PTA series=1996-1997 GM V6 and V8 truck gauge

SR series= standard Chrysler VPW gauge - typically 2001-2004)

CN series = standard GM CAN bus gauge

CNAV series = standard Volkswagen/Audi gas motor

CNAVD series = Volkswagen/Audi diesel motor

CND series = standard GM CAN bus gauge for 2006+ Duramax

CNF series=standard Ford CAN bus gauge

CNF11+series = Ford Ecoboost and 2011 and newer Mustang

CNC series=standard Chrysler CAN bus gauge

CNCDT series= Dodge Dart/Fiat CAN bus gauge

CNCJK series=Jeep Wrangler CAN bus gauge

CNI series = standard Asian import CAN bus gauge

CNAV series = standard Audi/VW CAN bus gauge

CANE series = standard European/some Asian CAN bus gauge

FD series = standard Ford gauge (pre-CAN)

ISOi series = standard Asian import gauge (pre-CAN)

ISOE = standard fast initialization application gauge (pre-CAN)

ISOAV = standard Audi/VW gauge (pre-CAN)

ISOEM=Mercedes engine monitor (pre-CAN)

CNMT=Mercedes transmission monitor for early Mercedes

Optional display colors available: blue/black, white/black, red/black and green/black.

PT101, FD101, CN101, SR101, etc: blue/black

PT201, FD201, CN201, SR201, etc.: white/black

PT401, FD401, CN401, SR401, etc.: red/black

PT501, FD501, CN501, SR501, etc: green black

Gauges come with black face and one two tone black/silver bezel as shown throughout website, but also include an additional white face allowing the user to customize the gauge's appearance.

Dual packages are also available.

Part number changes to PT202, CN102, etc. The last digit becomes a "2".

All versions are available in dual form except ISO gauges.

*Requires SR "second" gauge. State this when ordering

Chrysler				
All 2008+ Chrysler vehicles will us the CNC series gauge, CNCx01				
200	2011+	all gas	CNC series	CNCx01
300C	2005+	all	CNC series	CNCx01
300M	2002-2004	all	SR series	SRx01
Concord	2002-2004	all	SR series	SRx01
LHS	2002-2004	all	SR series	SRx01
PT Cruiser	2003-2005	all	SR series	SRx01
PT Cruiser	2006	1.6L	SR series	SRx01
PT Cruiser	2006+	2.4L	CNC series	CNCx01

Dodge				
Avenger	2008+	all	CNC series	CNCx01
Caliber	2006+	all	CNC series	CNCx01
Challenger	2008+	all	CNC series	CNCx01
Charger	2006+	all	CNC series	CNCx01
Dakota	2003-2004	4.7L	SR series	SRx01
Dakota	2005+	all	CNC series	CNCx01
Dart	2013+	all	CNDT	CNDTx01
Durango	2002-2003	4.7L	SR series	SRx01
Durango	2004+	all	CNC series	CNCx01
Intrepid	2003-2004	all	SR series	SRx01
Magnum	2005+	all	CNC series	CNCx01
Neon	2003-2005	all	SR series	SRx01
Nitro	2006+	all	CNC series	CNCx01
Ram	2003	4.7, 5.7	SR series	SRx01
Ram	2004-2005	all gas	SR series	SRx01
Ram	2006+	all gas	CNC series	CNCx01
SRT-4	2003-2005	all	SR series	SRx01
SRT-4	2008+	all	CNC series	CNCx01
Sebring	2003-2005	2.0L, 2.4L	SR series	SRx01
Sebring	2006+	all	CNC series	CNCx01
Stratus	2003-2006	2.0L, 2.4L	SR series	SRx01
Viper	2002-2006	V10	SR2 series	SRx01/2*
Viper	2007-2010	V10	CNV series	CNVx01

Jeep				
Commander	2006+	all	CNC series	CNCx01
Compass	2006+	all	CNC series	CNCx01
Grand Cherokee	2005+	all	CNC series	CNCx01
Liberty	2003-2005	all	SR series	SRx01
Liberty	2006+	all	CNC series	CNCx01
Patriot	2006+	all	CNC series	CNCx01
Wrangler	2005, 2006	all gas	SR series	SRx01
Wrangler	2007+	all gas	CNCJK series	CNCJKx01

FIAT				
500	2012+	all gas	CNCDT	CNCDTx01

General Motors				
All 2008+ General Motors vehicles will us the CN series gauge, CNx01 (except Duramax diesel which requires the CND series)				
Chevrolet				
Avalanche	2002-2006	all	PT series	PTx01
Avalanche	2007+	all	CN series	CNx01
Blazer	1996-2005	all	PT series	PTx01
Camaro	1996-2003	all	PT series	PTx01
Camaro	2010+	all	CN series	CNx01
Cavalier	1996-2005	all	PT series	PTx01
Cobalt	2005-2007	2.0L SC ed	PT series	PTx01
Cobalt	2005 - present	2.2L, 2.4L	CN series	CNx01
Cobalt	2008+	2.0L turbo	CN series	CNx01
Colorado	2004-2007	all	PT series	PTx01
Colorado	2008+	all	CN series	CNx01
Corvette	1996-2004	all	PT series	PTx01
Corvette	2005-present	all	CN series	CNx01
Cruze	2011+	all	CN series	CNx01
HHR	all	all	CN series	CNx01
Impala	1996-2005	3.8L, 5.7L	PT series	PTx01
Impala	2006-present	3.5L, 3.9L, 5.3L	CN series	CNx01
Malibu	1997-2004	all	PT series	PTx01
Malibu	2005-present	all	CN series	CNx01
Monte Carlo	1996-2005	3.8L	PT series	PTx01
Monte Carlo	2005-present	5.3L	CN series	CNx01

Monte Carlo	2006+	3.9L	CN series	CNx01
S-10	1996-2003	all	PT series	PTx01
SSR	2003-2004	5.3L	PT series	PTx01
SSR	2005-2006	6.0L	CN series	CNx01
Silverado	1996-1997	5.7L	PTA series	PTAx01
Silverado	1998-2006	all gas	PT series	PTx01
Silverado	1998-2007	8.1L	PT series	PTx01
Silverado	2007+	all gas	CN series	CNx01
Silverado	2000-2005	diesel	PT series	PTx01
Silverado	2006-2014	diesel	CND series	CNDx01
SS	2014+	all	CN series	CNx01
Sonic	2012+	all	CN series	CNx01
Suburban	1996-1997	5.7L	PTA series	PTAx01
Suburban	1998-2006	all	PT series	PTx01
Suburban	2007+	all	CN series	CNx01
Tahoe	1996-1997	5.7L	PTA series	PTAx01
Tahoe	1996-2006	all	PT series	PTx01
Tahoe	2007+	all	CN series	CNx01
Trailblazer	2000-2007	4.2L	PT series	PTx01
Trailblazer	2008+	4.2L	CN series	CNx01
Trailblazer	2005-present	5.3L, 6.0L	CN series	CNx01

Buick				
Enclave	2008+	all	CN series	CNx01
Regal	1996-2004	all	PT series	PTx01
Regal	2009+	all	CN series	CNx01
Riviera	1996-1999	all	PT series	PTx01
Roadmaster	1996	5.7L	PT series	PTx01
Rendezvous	2002-2003	all	PT series	PTx01
Rendezvous	2004-2007	3.4L	PT series	PTx01
Rendezvous	2004+	3.6L	CN series	CNx01
Ranier	2004-2007	4.2L	PT series	PTx01
Ranier	2005+	5.3L	CN series	CNx01
LaCrosse	2005-2007	3.8L	PT series	PTx01
LaCrosse	2005+	3.6L	CN series	CNx01
LaCrosse	2008	5.3L	CN series	CNx01
all others	1996-2005	all	PT series	PTx01
Cadillac				
ATS	all	all	CN series	CNx01
CTS	2003-present	all	CN series	CNx01
CTS-V	2004, 2005	LS6	PT series	PTx01
CTS-V	2006-present	LS2	CN series	CNx01
Escalade	2003-present	all	CN series	CNx01
SRX	2004-present	all	CN series	CNx01

GMC				
Envoy	2003-2007	4.2L	PT series	PTx01
Envoy	2005+	5.3L	CN series	CNx01
Jimmy	1996-2005	all	PT series	PTx01
Savana	1996-2006	all	PT series	PTx01
Savana	2007+	all	CN series	CNx01
Sierra	1996-1997	5.7L	PTA series	PTAx01
Sierra	1998-2006	all gas	PT series	PTx01
Sierra	2007-present	all gas	CN series	CNx01
Sierra	2000-2005	diesel	PT series	PTx01
Sierra	2006-present	diesel	CND series	CNDx01
Yukon	1996-1997	5.7L	PTA series	PTAx01
Yukon	1998-2006	all	PT series	PTx01
Yukon	2007-present	all	CN series	CNx01

Hummer				
H1	1996-2006	all	PT series	PTx01
H2	2003-2007	all	PT series	PTx01
H2	2008+	all	CN series	CNx01
H3	2005-2007	all	PT series	PTx01
H3	2008+	all	CN series	CNx01

Pontiac				
Bonneville	1996-2005	3.8L	PT series	PTx01
Bonneville	2005	5.3L	CN series	CNx01
Firebird	1996-2003	all	PT series	PTx01
Grand Prix	1997-2007	3.8L, 3.4L	PT series	PTx01
Grand Prix	2008	3.8L	CN series	CNx01
Grand Prix	2005-2008	5.3L	CN series	CNx01
Grand Am	1996-present	all	PT series	PTx01
GTO	2004	5.7L	PT series	PTx01
GTO	2005-2006	6.0L	CN series	CNx01
G5	all	2.2, 2.4L	CN series	CNx01
G6	all	all	CN series	CNx01
G8	all	all	CN series	CNx01
Solstice	all	all	CN series	CNx01
Torrent	all	all	CN series	CNx01

Saturn				
Ion Redline	2004-2007	2.0L	PT series	PTx01
Ion	2003-2007	2.2L, 2.4L	CN series	CNx01
Sky	all	all	CN series	CNx01

FIAT				
500 incl. Abarth	2012-2016	all	CNCDT	CNCDTx01

Ford				
All 2008+ Ford vehicles will use the CNF series gauges, CNFx01/CNFx02				
Cobra	1996-2004	all	FD series	FDx01
Cobra	2007	all	CNF series	CNFx01
Contour	1996-2000	all	FD series	FDx01
Crown Vic.	1996-2004	all	FD series	FDx01
Crown Vic.	2005+	all	CNF series	CNFx01
Escape	2001-2004	all	FD series	FDx01
Escape	2005+	all	CNF series	CNFx01
Escort	1996-2003	all	FD series	FDx01

Excursion	2000-2003		all gas		FD series		FDx01
Excursion	2004-2005		all gas		CNF series		CNFx01
Excursion	2000-2005		V10		FD series		FDx01
Excursion	2000-2003		7.3 diesel		FD series		FDx01
Excursion	2003-2005		6.0 diesel		CNF series		CNFx01
Expedition	1996-2004		all		FD series		FDx01
Expedition	2005-present		all		CNF series		CNFx01
Explorer	1996-2003		all		FD series		FDx01
Explorer	2004+		all		CNF series		CNFx01
Explorer	2010+		Ecoboost		CNF11+		CNFx0111+
F-150	1996-2003*		all		FD series		FDx01
F-150	2010-present		Ecoboost		CNF11+		CNFx0111+
F-150	2004 present		all		CNF series		CNFx01
F-2/3/450	1994-2002**		7.3L diesel		FD series		FDx01
F-2/3/450	2003-2010		6.0L diesel		CNF series		CNFx01
F-150 Lightning	1999-2004		all		FD series		FDx01
Fiesta	2013+		Ecoboost		CNF11+		CNFx0111+
Five Hundred	2005+		all		CNF series		CNFx01
Focus	2000-2004		2.0L		FD series		FDx01
Focus	2004+		2.3L		CNF series		CNFx01
Focus ST	2010-present		Ecoboost		CNF11+		CNFx0111+
Focus	2005+		all		CNF series		CNFx01
Freestyle	2005+		all		CNF series		CNFx01
Fusion	2010+		Ecoboost		CNF11+		CNFx0111+
Fusion	2006+		all		CNF series		CNFx01
Mustang	1996-2004		all		FD series		FDx01
Mustang	2005-2010		all		CNF series		CNFx01
Mustang	2011- pres.		all		CNF11+		CNFx0111+
Probe	1996-1997		all		ISOI series		ISOIx01
Ranger	1996-2006		all		FD series		FDx01
Ranger	2007+		a		CNF series		CNFx01
Taurus	1996-2003		all		FD series		FDx01
Taurus SHO	2010-present		Ecoboost		CNF11+		CNFx0111+
Taurus	2004+		all		CNF series		CNFx01
Thunderbird	2003-2005		all		CNF series		CNFx01
Thunderbird	1994-1997		all		FD series		FDx01

*Through August of 2003. F-150's made after 8/03 us CAN

**All 7.3L use the FD series, all 6.0L use the CNF series

Hyundai							
All 2008+ Hyundai vehicles will use the CNE series gauges, CNEx01/CNEx02							
Kia							
All 2008+ Kia vehicles will use the CNE series gauges, CNEx01/CNEx02							

Lincoln							
Blackwood	2002		all		FD series		FDx01
LS	2000-2002		all		FD series		FDx01
LS	2003-2006		all		CNF series		CNFx01
Mark 8	1996-1998		all		FD series		FDx01
Mark LT	2006+		all		CNF series		CNFx01
MKS	All		all		CNF series		CNFx01
MKZ	2007+		all		CNF series		CNFx01
MKZ	All		all		CNF series		CNFx01
Navigator	1998-2004		all		FD series		FDx01
Navigator	2005+		all		CNF series		CNFx01
Town Car	1996-2004		all		FD series		FDx01
Town Car	2005+		all		CNF series		CNFx01
Zepher	2006		all		CNF series		CNFx01

Mercury							
Cougar	1999-2002		all		FD series		FDx01
Grand Marquis	1996-2004		all		FD series		FDx01
Grand Marquis	2005+		all		CNF series		CNFx01
Marauder	2003-2004		all		FD series		FDx01
Mariner	2005+		all		CNF series		CNFx01
Milan	2006+		all		CNF series		CNFx01
Montego	2005+		all		CNF series		CNFx01
Montey	2007+		all		CNF series		CNFx01
Mountaineer	1996-2003		all		FD series		FDx01
Mountaineer	2004+		all		CNF series		CNFx01
Sable	2004+		all		CNF series		CNFx01

Mazda							
All 2008+ Mazda vehicles will use the CNI series gauges, CNix01							
626	1999-2002		all		ISOI series		ISOIx01
CX-7	2007+		all		CNI series		CNix01
CX-9	2007+		all		CNI series		CNix01
Miata	1996-2005		all		ISOI series		ISOIx01
Miata	2006+		all		CNI series		CNix01
Millenia	1996-2003		all		ISOI series		ISOIx01
Mazda3	2004+		all		CNI series		CNix01
Mazda5	1999-2005		all		ISOI series		ISOIx01
Mazda6	2003+		all		CNI series		CNix01
MX-3	1996-1998		all		ISOI series		ISOIx01
MX-6	1996-1997		all		ISOI series		ISOIx01
Protégé	1996-2003		all		ISOI series		ISOIx01
RX-8	2004+		all		CNI series		CNix01
Tribute	2001-2004		all		FD series		FDx01
Tribute	2005+		all		CNF series		CNFx01

Mercedes							
CLS55	2006		all		ISOEM***		ISOEMx01
CLS55	2006		all		CANMT****		CANMTx01
E Class	2003-2006		all		ISOEM***		ISOEMx01
E Class	2003-2006		all		CANMT****		CANMTx01
S Class	2003-2005		gas		ISOEM***		ISOEMx01
S Class	2003-2005		gas		CANMT****		CANMTx01
SL	2003-2005		gas		ISOEM***		ISOEMx01
SL	2003-2005		gas		CANMT****		CANMTx01

***for engine parameter monitoring
****for transmissoin parameter monitoring

Many others from 1996-2007 are supported but testing is not complete. Contact sales@aeroforcetech.com for details.

Mini							
Cooper	2001-2006		all		ISOi		ISOix01
Cooper R56 Hardtop	2007+		all		CNE		CNEx01
Cooper R57 Conv.	2007, 2008		all		ISOi		ISOix01
Cooper R57 Conv.	2009		all		CNE		CNEx01
Cooper Clubman	2008+		all		CNE		CNEx01
Cooper (all)	2009+		all		CNE		CNEx01

Mitsubishi

All models made from 1996 to 2007 will use the ISOi series gauge

All models made from 2008+ will use the CNI series gauge

Nissan

All models made from 1996 to 2006 will use the ISOi series gauge (not yet available)***

All models made from 2007+ will use the CNI series gauge*** *** excluded all diesel models

Porsche

All gasoline models made from 2008+ will use the CNE series gauge, as will the 2007 911. Models prior to 2007 are not supported at this time.

Saab

9-3 Aero	2005-2012		V6 - 2.8L		CANSB		CANSBx01
9-5 Aero	2010-2012		V6 - 2.8L		CANSB		CANSBx01

Scion

All models made from 2001 to 2005 will use the ISOi series gauge

All models made from 2006+ will use the CNI series gauge

Subaru

BRZ	2012+		gas		CANE		CANEx01
Forester	2006-2014		gas		CNSSM		CNSSMx01
Impreza	2006-2014		gas		CNSSM		CNSSMx01
Legacy	1996-2006		gas		CNSSM		CNSSMx01
Legacy	2006-2014		gas		CNSSM		CNSSMx01
Outback	2006-2014		gas		CNSSM		CNSSMx01

Toyota

All 2007+ Toyota vehicles will use the CNI series gauges. CNix01

4Runner	1998-2004		all gas		ISO series		ISOix01
4Runner	2005+		all gas		CNI series		CNix01
Avalon	1996-2004		all gas		ISO series		ISOix01
Avalon	2005+		all gas		CNI series		CNix01
Camry	1998-2006		all gas		ISO series		ISOix01
Camry	2007+		all gas		CNI series		CNix01
Celica	1998-2005		all gas		ISO series		ISOix01
Celica	2006		all gas		CNI series		CNix01
Corolla	1998-2006		all gas		ISO series		ISOix01
Corolla	2007+		all gas		CNI series		CNix01
FJ Cruiser	2007+		all gas		CNI series		CNix01
FR-S	2012+		all gas		CNE series		CNEx01
Highlander	2001-2006		all gas		ISOi series		ISOix01
Highlander	2007+		all gas		CNI series		CNix01
Land Cruiser	1998-2005		all gas		ISOi series		ISOix01
Land Cruiser	2006+		all gas		CNI series		CNix01
MR2	1998-2005		all gas		ISOi series		ISOix01
MR2	2006+		all gas		CNI series		CNix01
RAV4	1998-2005		all gas		ISOi series		ISOix01
RAV4	2006+		all gas		CNI series		CNix01
Sienna	1998-2006		all gas		ISOi series		ISOix01
Sienna	2007+		all gas		CNI series		CNix01
Sequoia	2001-2004		all gas		ISOi series		ISOix01
Sequoia	2005+		all gas		CNI series		CNix01
T100	1998		all gas		ISOi series		ISOix01
Tacoma	1998-2004		all gas		ISOi series		ISOix01
Tacoma	2005+		all gas		CNI series		CNix01
Tundra	1999-2004		all gas		ISOi series		ISOix01
Tundra	2005+		all gas		CNI series		CNix01

Volkswagon

All models made from 2008-2014 will use the CNAV series gauge. 2015+ coming soon

CC	2011 - 2014		all gas		CNAV		CNAVx01
Beetle	2008-2014		all gas		CNAV		CNAVx01
Golf/GTI	2000-2005		all gas		ISOAV		ISOAVx01
Golf/GTI	2006-2014		2.0L turbo		CNAV		CNAVx01
Golf	2006-2014		diesel		CNDVAV		CNDVAVx01
Jetta	2000-2005		all gas		ISOAV		ISOAVx01
Jetta	2006-2014		2.0L turbo		CNAV		CNAVx01
Jetta	2006-2014		diesel		CNDVAV		CNDVAVx01
Passat	2000-2005		all gas		ISOAV		ISOAVx01
Passat	2006-2014		2.0L turbo		CNAV		CNAVx01

*These are currently tested models. It's possible that many others are also supported or soon will be with the current version but they must be tested first before we can add them to the list.